



FORD TRANSIT REAR A/C VENT ADAPTER

3-Port (2.5") Hose Adapter – Installation Guide

Converts the Ford Transit factory rear A/C outlet into three 2.5" duct ports for routing airflow through van interiors, partitions, and upfit systems.

Fitment: Ford Transit factory rear A/C systems (2015–present).



Before You Install: Verify rear A/C is present, test airflow, and ensure outlet surface is clean.

Specifications

- 2.5" outlets (x3)
- Black finish
- Direct OEM fit

What's Included

- (1) Vent Adapter
- Hardware not included

Recommended Accessories



2.5" Hose



Y Connector



2"–3" Clamp

Installation Steps

1. Apply foam seal tape if needed.
2. Pre-drill pilot hole for screws to prevent cracking or chipping of adapter.
3. Secure adapter using self-tapping screws (do not overtighten).
4. Seal seam with HVAC foil tape to reduce noise and leaks.
5. Attach ducting and secure with worm gear clamps.

Airflow Note: Splitting airflow reduces output per vent. Keep duct runs short for best performance.

Troubleshooting: Check for loose connections, kinks, or air leaks if airflow is low.

Installation Orientation: Install flush to factory outlet and align ports to routing direction.